

R-9050

BOXSTER ROLL BAR EXTENSION PADDING KIT
INSTALLATION INSTRUCTIONS

The R-9050 pad kit has been designed to provide a 1" thick high density pad to guard against helmet to bar contact. The R-3010 roll bar extension and the R-9050 pad kit has been designed for driver's ed use only.

Step 1.

Position pads on the bar as shown.



Step 2.

Fasten pads to bar using caps and supplied hardware. Do not over tighten.

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.