

# **Porsche 981 Boxster PDK** **Stainless Steel Sports Centre Grille**

**Kit Contents: -**

- 1 off Centre Grille
- 2 off No 6 x 2" Screws

**Centre Mesh Grille Fitting Instructions**

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Locate Grille Level with aperture as shown in fig1.
3. Insert the screw into the diamond through mesh and tighten down as shown in fig 2 then repeat to the opposite diamond (do not over tighten).
4. Remove the tape and the grilles are now complete.

**Fig 1****Fig 2**